



---

## **'Vanorak' roofless roof cover fitting instructions**



### Step 1

Remove cover from its carry bag and lay out on the ground next to the passenger side of your California, ensuring that the soft lining is facing upwards and that the front of your cover (with the third window and Campervantastic logo) are forward.

### Step 2

Take hold of the white beading at the front corner of your cover, which should be nearest to your California, and begin to feed the beading in to the aluminium awning rail which runs along the passenger side of your vehicle. Start at the rear and feed it along until the cover is attached from front to back. The cover should hang down with the soft lining facing out.



### Step 3

Raise the roof to about a third up and walk the front of the topper around the van. You will then need to carefully open the passenger door to stand on the step and hook the front left corner over the roof. Do the same on the driver's side. (In windy conditions you may need the assistance of a second person, or else park your vehicle so that the wind is blowing across your California roof from the passenger side towards the driver's side, this will greatly assist and the vehicle can be turned around afterwards if required).



### Step 4

Hook the middle support over the roof of the van and fasten with the Velcro. Follow this by hooking the rear corners around and fasten the topper together with the Velcro.



### Step 5

Once all four corners are correctly in place, continue raising the roof as per your manufacturer's instructions. When the roof is fully raised the cover should fit nicely along the passenger side and the driver's side should be hanging down with the 5 clips ready to attach.



### Step 6 (No fixed awning)

If your California is not fitted with a fixed roll out awning, simply undo the 5 clips, slide them along the awning rail, clip them all in to place and gently tighten the adjustable straps so that the cover fits neatly all the way along (do not over tighten as you do not want to exert excessive pressure on the roof of your California).

#### Step 6 (with fixed awning)

If your California is fitted with a fixed roll out awning, undo the two clips at the front and one at the rear, slide the front two in to the aluminium awning rail from the front, attach them to the clips on the cover and tighten (do not over tighten straps). Slide the rear clip into the aluminium awning rail at the back and attach it to the rear strap before tightening (do not over tighten straps).



#### Step 7

Two further straps are fitted to the rear of your Vanorak. These straps may either be passed around the inside of the rear door hinges of your tailgate, or alternatively, if your vehicle is fitted with a rear door mounted bicycle carrier, they can be fixed to a suitable area of that.



Your Vanorak will fit securely to your Volkswagen California providing increased insulation and protection to the roof bellows. To remove the cover simply follow the instructions in reverse, remembering to undo all clips prior to lowering roof, then remove the rear corners first for ease of removal.

We hope that your new Vanorak extends your enjoyment of this wonderful vehicle. Please do not hesitate to get in touch if you require any further advice/assistance.

**[www.campervantastic.com](http://www.campervantastic.com)**