



Fitting your new SpaceMate to: 3-Seater Beach

Step 1: Rear Bench Seat Setup

Begin by placing the rear bench seat in the furthest rear position within your California.

Step 2: T Bolt Installation

Measure a distance of 750mm from the edge of the boot trim. Insert a T bolt at the marked position.

Take note of the markings on the top of the T bolt and rotate 90 degrees while lightly pulling upwards until it securely locates in a slot.

Step 3: Adding Washers and Half Nut

(i) Fit the large nylon washer to protect the rail system.

(ii) Follow with the large steel washer.

(iii) Next, fit the slimmer half nut onto the T bolt to keep it in place whilst lifting the Spacemate into place. **(Tip!)** Gently pull on the bolt, use your fingers to secure the T bolt in its place.



Not using the fittings in this order may cause the T Bolts to damage the rail or the SpaceMate Drawer.

Step 4: Checking for Level

After fitting both T bolts, check that they are level with one another.

Step 5: Final Tightening

Use a 13mm spanner to firmly tighten the T bolts, maintaining their level position. These bolts can now be left in position even if you remove the SpaceMate.

Step 6: SpaceMate Drawer Installation

Carefully slide the SpaceMate back into position, pushing all the way back to the T bolt fittings being mindful not to damage your interior. The rubber foam on the bottom of your SpaceMate will prevent damage to the rail system.

Open the latch and pull the drawer open approximately 100mm. With the assistance of two people, raise the rear subframe and lower it onto the T bolts.

Secure the subframe in place using either the Nyloc nut or wing nut provided.

Your SpaceMate is now correctly installed and ready for use. Have fun and enjoy the practicality of your new SpaceMate.

When you're ready, come back and take a look at the SpaceMate Rear Hook on Kitchen and use the Offer Code SMDK23 for free shipping.

