

Pitching & Striking Instructions for :-

HUB CANOPY

Visit our YouTube Channel for an instructional video of this model

WARNING:

If this awning is not erected in accordance with the instructions damage could be caused to the joints, poles or fabric. It is important that the awning is properly guyed at all times, particularly in strong winds otherwise damage could occur

DO NOT PUSH TENT PEGS IN BY HAND, ALL TENT PEGS SHOULD BE DRIVEN HOME USING A WOODEN OR RUBBER MALLET

Pitching your canopy

<u>кнү м</u>





1. Remove the canopy from its carry bag, and unfold roof section Canopy can be attached onto any of the 3 open sides





2. Attach clips of the front section above and below auto joint on main awning.





Throw roof section of canopy over roof of tent/awning.
*Tip – If you are struggling to reach for this, assemble one of the poles and attach to corner clip, you will then be able to pull panel over towards you





 Secure clips onto pole above auto joint, Once the roof is clipped in place secure 1st Velcro around centre of Auto Joint (padded cover can be removed if you prefer) Lastly secure Velcro/Clip around pole underneath Auto Joint and tighten webbing to pull corner down

Pitching your canopy

<u>кнү</u> <u>м</u>





6. Assemble fibreglass pole and insert into sleeve on front of canopy Secure plastic joints onto each end of the pole





7. Assemble black steel poles (x2) and insert blank end into plastic joint

Secure spiked end of pole into eyelet strap on canopy





8. Repeat step 7 on remaining side pole, secure clips up sides of poles





9. Secure guy lines and peg out base of Hub Canopy, attach clips down side of canopy to main tent/awning poles